

● Easel



WE 3030

● Paper Punch



WOT 4007

● RF Flash Trigger




● Photo Box



Sizes Available :
 40 x 40 x 40 cm
 60 x 60 x 60 cm
 75 x 75 x 75 cm
 (provided with 4 coloured backdrops)

● Colour Enlargers



Meopta Axomat 5


Meopta Opemus 7

● Super Clamp




Super Clamp SA - 35

Accessory for Super Clamp : Double Sided Spigot.



The Double Sided Spigot can be fitted into the Super Clamp. This arrangement can be used to mount lights from the ceiling or any vertical pole. (Pic. 1 & 2).

Accessory for Super Clamp : Extension Arm



The Extension Arm can be fitted into the Super Clamp. This arrangement can be used to mount lights from the ceiling or any vertical pole.

● Lens Cleaning Kits



Cleaning Kit WOA 2009


Contents : Cleaning cloth, Tissue, Cotton swab, Anti-fog lens spray (20 ml.) & Blower brush.



Cleaning Kit WOA 2010

Contents : Cleaning cloth, Tissue, Cotton swab, Cleaning liquid (35 ml.) & Blower brush.

● Dolly



Dolly FT-9901

Dolly WT-600



The legs of the dolly fold together making it easy to store and portable.



Camera tripods can easily be mounted onto the dolly.