



**Contents :**

- LEFT-SIDE A-SUPPORT
- RIGHT-SIDE A-SUPPORT
- TOP SUPPORT TUBE
- FRONT SUPPORT TUBE
- REAR-LOWER SUPPORT TUBE
- FRONT-LOWER SUPPORT TUBE
- ROUND KNOBS 6 pc.
- WING KNOBS 4 pc.
- PHOTO TABLE SHEET
- Carry Bag

NOTE : Step 1,2,3 and 4 are to be done with the photo-table parts lying flat on the ground.

**Step 1 :**

Lay out the left side A-Support and the right-side A-Support as shown in pic

**Step 2 :**

Using the round knobs provided attach the front-lower support tube from both ends.

**Step 3 :**

Using the round knobs provided attach the rear-lower support tube from both ends.

**Step 4 :**

Using the round knobs provided attach the front support tube

NOTE : The locking brackets should be facing downwards.

**Step 5 :**

Open the photo table chassis - it should look like this

**Step 6 :**

Using the wing knobs provided attach the top support tube

**Step 7 :** Slide the edges of the plastic sheet as shown. First slide the top edge (A) under the locking brackets. Then press down at the center of the sheet (B) to enable the lower edge (C) to slide into the locking brackets easily. (The matte surface should stay on the top)

**To add lights :**

Fig. 8.a. a.) Can fit the HARISON extension arm to attach lights (fig. 8.a.)

Fig. 8.b. b.) Can use HARISON C-Clamp SP to fit a light at the bottom to get rid of shadows (fig. 8.b.)